

Quick Start Guide

Thank you for choosing Therma. Here's how you get set up in three simple steps:

1. Place your Therma° hub on the same floor as the equipment you'd like to monitor. Choose an area with a good cellular signal. Screw on both antennas, point them toward the sky, and plug in your hub. You'll know you're online when the globe LED is illuminated in solid red.
2. Place the sensor inside the equipment you'd like to monitor and attach via zip ties and/or double-sided velcro. Press the ACT button on the bottom of your sensor until the light flashes to activate.
3. Place your sensor in the middle of your unit, away from fans and doors. Do not place the sensor within or on top of food, in water, above heat or fire, or in ziplock bags.

Set up your location and sensors at dashboard.hellotherma.com/sensors or via the **Therma mobile app**.

**Questions? Visit hellotherma.com/resources.
We're also available via email and chat 24/7.**

support@hellotherma.com
hellotherma.com

Installation Tips:

1. After placing your sensor, wait one hour for the sensor to acclimate to its new environment before using temperature readings.
2. After you've set up your Therma° system, allow the sensors to collect temperature data for at least 2 days. Use the initial temperature data to make adjustments to your environmental controls before setting alerts. This will prevent you from receiving a large volume of alerts on your first day.

Scan the QR code on the left for the detailed installation guide.

Our app can be downloaded on Apple App Store and Google Play.



Therma°
Installation Guide

